


**air#**  
Fan Unit


## How to Attach the Fan Unit

### 1 Detaching the air valve cover




To detach, simply turn the air valve cover counterclockwise.

### 2 Attaching the fan unit



To attach, turn the fan unit clockwise.


## How to Charge the Fan Unit



Plug the charging cable into the USB terminal and connect it to the power adapter to start charging. When charging, be sure to use a DC 5V, 1A power adapter. Do not operate the product while charging the fan unit.

- \* Be sure to avoid charging the product near a heating apparatus or in a high-temperature environment.
- \* To minimize the risk of damage or fire, do not cover the device with any objects. (blanket, towel, etc)
- \* Keep the fan unit away from magnets and direct magnetic fields, as they can cause malfunction.
- \* If you find any abnormalities with the battery such as swelling, stop using it immediately and contact the place of purchase.
- \* Do not attempt to disassemble the fan unit. Disassembly will void the warranty and the unit will no longer be eligible for any warranty services.

## Fan unit part names and operation instructions



## Specification

Weight	24g
Dimension	76.3mm*40.5mm*8.7mm
Battery	250mAh / 3.7V
Operation Hours	Normal speed : Normal charge for about 3 hours and 30 minutes / Fast speed : Fast charge for 2 hours and 40 minutes
Charging Hours	Approximately 2 hours and 30 minutes (5A/1A power adapter)

### EU-Declaration of Conformity

EU-Declaration of Conformity can be found at [www.cowonglobal.com/eu\\_doc](http://www.cowonglobal.com/eu_doc)

Product specification may change without prior notice.  
Images contained in this page may vary from the actual product.

